# **HIQ Universe**

### cloud service for internet access

**HIQ Universe** 

# **Create HIQ Universe account**

HQ Universe   Sign in × +		- 0 ×
O  https://my.biq-home.com/n/se/login/index	C Q. Search	☆ 白 ♣ ☆ ◙ @ ≄ - ☰
HIQ Universe		
	Your home, smart	er
		Email
		Password
	Keep me logged in	
	Submit	
	Forgot your password?	-
	Create new account	
-Acobotioa		Contact
copyright (c) 1998-2016, all rights reserved		Privacy Terms

### Go to HIQ Universe: HIQ Universe

HBQ Universe   Create new × +		- 0 ×
0 A https://my.kiq-home.com/m/ss/register/index	C <sup>e</sup> Q. Search	☆ 白 ♣ ☆ ♡ @ ♥ - ☰
HIQ Universe		-
	Create new accoun	t
	goran.kocjancic@robotina.si	Email
	•••••	Password
	•••••	Repeat password
	Accept Terms and Conditions	
	Visem robot.	
	Submit	
<del>d</del> erobotina		Contact Privacy
copyright (c) 1998-2016, all rights reserved		Terms

### Create and log in into account

## Add controller to HIQ Universe



**Get Controller serial number** Open HIQ Configurator. Controller serial number is under "Autodetect" button on "System" page.

HQ Configurator v1.2.9				_ <b>_</b> ×
System setup				Lights+blinds Scene editor
				Ready light
Display brightness		Test F D		Timetable
		scene	$\square$	Automation
100 m	scene 0 scene 1 scene 2 scene 3	scene 16 scene 17 scene 18 scene 19	enable Test	Alarm Energy
by night			push timer: 23s messages: 2/4 roundtrip: 22ms	System Exit
backlight	scene 8 scene 9 scene 10 scene 11	scene 24 scene 25 scene 26 scene 27	authantification	
	scene 12 scene 13 scene 14 scene 15	scene 28 scene 29 scene 30 scene 31	code: 553151 valid: 588s	
Display brightness by day and by night. Bicklight to a wake filomentarion, you'd to locate panel in darkness (Cr. cnig). Update button is used when new devices are connected.	Selected scene will be transmitte synchronize both ways, also selec Controllers must be in the same r allowed.	d to all HIQ controllers. To 4 scene on other controller(5). Heetwork, broadcast must be	Enable to establish internet connection. When disabled, no data is sent out of local network. Authentification is used to confirm the ownership when creating a new account.	
Real-time clock 2011 03 22 wed 12 20 03 - 0 year month date weekday hour min set time zone				
Settings common for all connected devices. Scene link is used to synchronize a scene between two or more HIQ controllers. It can be used, for example, to turn all the lights off. Internet access is used with mobile application (HIQ Commander), and web server (HIQ Universe). Real-time clock is used for timetable and low light calculation.				

Enable internet access and get authentication code

2025/08/25 12:11



3/9

#### Add HIQ controller



**Check controller status** 

# **Connect HIQ Commander through HIQ Universe**



### Download and install HIQ Commander

On smartphone (Android or iOS) go to PlayStore or App Store. Find and install HIQ Configurator app.

2025/08/25 12:11



## Set HIQ Commander permissions

Go to "Settings - Apps"

Find and select "HIQ Commander"

Click on "Permissions"

Enable all App permissions.

Last update: 2018/10/05 13:09



**Autodetect HIQ System** 



#### Accept detected system

Set location: used to calculate sunrise and sunset directly in HIQ Controller.

Set time and date: synchronize HIQ Controller time and date with smartphone.

Enable internet access: HIQ controller can be controlled from everywhere through HIQ Universe.

Select "Disable" if any of the services is not available on your device, otherwise Autodetect will not be possible.

<b>A</b>	* 🔽 🕖 12:37
HIQ Commander	
I'm home	
Scene	00
Scene	01
Scene	02
Scene	03
Scene	04

# HIQ Configurator is set to work through HIQ Universe when you are not at home



### You can change connection mode later

Press three lines on upper right corner and select "Settings"

