Power sensor management

Default address on all power sensor is 149.

Available addresses for sensors are listed in table.

Note: adding of power sensor is supported one by one.

Address	Power sensor position	
150	Grid	For both type of power sensor apply:
154,155,156 157,156 by fo 161167 play	PV to communication bus, Battery of press and hold Consumer	the push-button on the power sensor until it appears -SEt- on

- it should appear in configurator as new device, click on button **add** next to the source or consumer where sensor should be assigned,
- repeat procedure for next PM1-E-D or PM3-E-D.

Note: For PM3-E-D is possible to set address manually according to table, before adding it to communication bus:

Without grid power sensor

• **Virtual grid PS** is an option if no grid meter is used. Power, current and energy will be calculated from other power sensors.

Delete power sensor

One-phase sensors PM1-E-D

- Make sure the "new device" is empty
- Press the button on power-sensor until **-Set-** appears on the display
- In HEMS Configurator press "del" button next to the sensor
- After a few seconds, the sensor should appear as the "new device"
- If desired, the sensor can be removed or it can be assigned to another device

Three-phase power-sensor

- Make sure the "new device" is empty
- In HEMS Configurator press "del" button next to the sensor
- After a few seconds, the sensor should appear as the "new device"
- If desired, the sensor can be removed or it can be assigned to another device

Last update: en:robotina_charger:commissioning:power_sensor http://wiki.hiq-home.com/doku.php?id=en:robotina_charger:commissioning:power_sensor&rev=1671092333 08:18

From:

http://wiki.hiq-home.com/ -

Permanent link: http://wiki.hiq-home.com/doku.php?id=en:robotina_charger:commissioning:power_sensor&rev=1671092333

Last update: 2022/12/15 08:18



http://wiki.hiq-home.com/ Printed on 2025/12/05 16:48