

HIQ

robotina

## HIQ PM-3-E-D-CT

*Din Rail Power Sensor for Single and Three Phase Electrical Systems*



- Measures kWh Kvarh, KW, Kvar, KVA, P,
- F, PF, Hz, dmd, V, A, THD, etc.
- Bi-directional measurement IMP & EXP
- Two pulse outputs
- RS485 Modbus
- Din rail mounting 35mm
- 0.33V CT connection
- Better than Class 1 / B accuracy

## **1. Introduction**

This document provides operating, maintenance and installation instructions. The unit measures and displays the characteristics of three phase four wires(3p4w) supplies, including voltage, frequency, current, power, active and reactive energy, imported or exported. Energy is measured in terms of kWh, kVAh. Maximum demand current can be measured over preset periods of up to 60minutes. In order to measure energy, the unit requires voltage and current inputs in addition to the supply required to power the product. The requisite current input(s) are obtained via current transformers (CT).

This power sensor can be configured to work with a wide range of CTs with 0.33V output, giving the unit a wide range of operation. Built-in interfaces provide pulse and RS485 Modbus RTU outputs. Configuration is password protected.

This unit can be powered from a separate auxiliary (AC or DC) supply. Alternatively, it can be powered from the monitored supply, where appropriate.

### **1.1 Unit Characteristics**

The Unit can measure and display:

- Line voltage and THD% (total harmonic distortion) of all phases
- Line Frequency
- Currents, Current demands and current THD% of all phases
- Power, maximum power demand and power factor
- Active energy imported and exported
- Reactive energy imported and exported

The unit has password-protected set-up screens for:

- Changing password
- Demand Interval time
- Reset demand measurements
- Pulse output duration

Two pulse output indicates real-time energy measurement. An RS485 output allows remote monitoring from another display or a computer.

### **1.2 Current Transformer Primary Current**

The unit can be configured to operate with CT with 0.333V output. The secondary CT is fixed at 0.333V, and the primary is optional.

### **1.3 RS485 Serial – Modbus RTU**




This uses an RS485 serial port with Modbus RTU protocol to provide a means of remotely monitoring and controlling the Unit

Set-up screens are provided for setting up the RS485 port. Refers to section 4

### 1.4 Pulse output

This provides two pulse outputs that clock up measured active and reactive energy. The constant for reactive energy is 3200imp/kVArh. The pulse width for active energy can be set from the set-up menu.





## 2. Start Up Screens

 <p>The first screen lights up all display segments and can be used as a display check.</p>	<p>The first screen lights up all display segments and can be used as a display check.</p>
 <p>The second screen indicates the firmware installed in the unit and its build number.</p>	<p>The second screen indicates the firmware installed in the unit and its build number.</p>
 <p>The interface performs a self-test and indicates the result if the test passes.</p>	<p>The interface performs a self-test and indicates the result if the test passes.</p>

After a short delay, the screen will display active energy measurements.





## 3. Measurements

The buttons operate as follows:

	<p>Selects the Voltage and Current display screens In Set-up Mode, this is the “Left” or “Back” button.</p>
	<p>Select the Frequency and Power factor display screens In Set-up Mode, this is the “Up” button</p>
	<p>Select the Power display screens In Set-up Mode, this is the “Down” button</p>
	<p>Select the Energy display screens In Set-up mode, this is the “Enter” or “Right” button</p>


### 3.1 Voltage and Current

Each successive pressing of the  button selects a new range:

	Phase to neutral voltages
	Current on each phase
	Phase to neutral voltage THD%
	Current THD% for each phase

### 3.2 Frequency and Power factor and Demand

Each successive pressing of the  button selects a new range:



	Frequency and Power Factor (total)
---	------------------------------------

	Power Factor of each phase
	Maximum Power Demand
	Maximum Current Demand

### 3.3 Power




Each successive pressing of the  button select a new range:




	Instantaneous Active Power in kW
	Instantaneous Reactive Power in kVAr

	Instantaneous Volt-amps in KVA
	Total kW, kVArh, kVA

### 3.4 Energy Measurements


Each successive pressing of the  button selects a new range:

	Imported active energy in kWh
	Exported active energy in kWh
	Imported reactive energy in kVArh

	Exported reactive energy in kVArh
	Total active energy in kWh
	Total reactive energy in kVAh

#### 4. Setting Up

To enter set-up mode, pressing the  button for 3 seconds, until the password screen appears.



Setting up is password-protected so you must enter the correct password (default '1000') before processing. If an incorrect password is entered, the display will show: PASS Err






To exit setting-up mode, press  repeatedly until the measurement screen is restored.



#### **4.1 Set-up Entry Methods**


Some menu items, such as password and CT, require a four-digit number entry while others, such as supply system, require selection from a number of menu options.




##### **4.1.1 Menu Option Selection**

1) Use the  and  buttons to select the required item from the menu. selection does not roll over between bottom and top of list

2) Press  to confirm your selection

3) If an item flashes, then it can be adjusted by the  and  buttons. If not, there maybe a further layer.



4) Having selected an option from the current layer, press  to confirm your selection. The SET indicator will appear.


5) Having completed a parameter setting, press  to return to a higher menu level. The SET indicator will be removed and you will be able to use the  and  buttons for further menu selection.


6) On completion of all setting-up, press  repeatedly until the measurement screen is restored.

##### **4.1.2 Number Entry Procedure**

When Setting up the unit, some screens require the entering of a number. In particular, on entry to the setting up section, a password must be entered. Digits are set individually, from left to right. The procedure is as follows:








1) The current digit to be set flashes and is set using the  and  buttons

2) Press  to confirm each digit setting. The SET indicator appears after the last digit has been set.

3) After setting the last digit, press  to exit the number setting routine. The SET indicator will be removed.



#### 4.2 Change password

	<p>Use the  and  to choose the change password option</p>
	<p>Press the  to enter the change password routine. The new password screen will appear with the first digit flashing</p>
	<p>Use  and  to set the first digit and press  to confirm your selection. The next digit will flash.</p>
	<p>Repeat the procedure for the remaining three digits</p>
	<p>After setting the last digit, SET will show.</p>
<p>Press  to exit the number setting routine and return to the Set-up menu.</p>	

#### 4.3 DIT Demand Integration Time


This sets the period in minutes over which the current and power readings are integrated for maximum demand measurement. The options are: off, 5, 10, 15 30,60 minutes

	<p>From the set-up menu, use  and  buttons to select the DIT option. The screen will show the currently selected integration time.</p>
	<p>Press  to enter the selection routine. The current time interval will flash</p>
	<p>Use  and  buttons to select the time required.</p>
	<p>Press  to confirm the selection. SET indicator will appear.</p>
<p>Press  to exit the DIT selection routine and return to the menu.</p>	

#### 4.4 CT








The CT option sets the primary current(CT2 fixed 0.333V) of the current transformer (CT) that wires to the power sensor.

	<p>From the Set-up menu, use  and  buttons to select the CT primary(CT1). Its' default 5A,and ranged from 0005 to 9999</p>
--	--

	<p>Secondary CT(CT2) It's fixed 0.333V, and can not be set.</p>
---	---

#### 4.5 PT

The PT option sets the secondary voltage (PT2 100 to 500V) of the Voltage transformer (PT) that wires to the power sensor.

	<p>From the Set-up menu, use  and  buttons to select the PT option. The screen will show the voltage PT secondary voltage value. The default value is 400V</p>
	<p>Secondary PT setting Press  to enter the PT secondary voltage selection routine. The range is from 100 to 500V</p>
	<p>Set PT ratios value Press  to enter the PT ratio screen. The range is from 0001 to 9999</p>
<p>For example, if set the ratio to be 100, it means the primary voltage equals secondary voltage x100</p>	

#### 4.6 Pulse output


This option allows you to configure the pulse output. The output can be set to provide a pulse for a defined amount of energy active or reactive.

Use this section to set up the relay pulse output—Units: kWh, kVAh

	<p>From the Set-up menu, use  and  buttons to select the Pulse output option.</p>
	<p>Press  to enter the selection routine. The unit symbol will flash.</p>
	<p>Use  and  buttons to choose kWh or kVArh.</p>
<p>On completion of the entry procedure, press  to confirm the setting and press  to return to the main set up menu.</p>	







#### 4.6.1 Pulse rate

Use this to set the energy represented by each pulse. Rate can be set to 1 pulse per 0.01kWh/0.1kWh/1kWh/10kWh/100kWh.



(It shows 1 impulse = 10kWh/kVArh)

	<p>From the Set-up menu, use  and  buttons to select the Pulse Rate option.</p>
--	---










	<p>Press  to enter the selection routine. The current setting will flash. 0.01/0.1/1/10/100kWh/kVArh per pulse</p>
<p>Use  and  buttons to choose pulse rate. On Completion of the entry procedure, press  to confirm the setting and press  to return to the main set up menu.</p>	

**4.6.2 Pulse Duration**

The energy monitored can be active or reactive and the pulse width can be selected as 200, 100 or 60ms.



(It shows pulse width of 200ms)

	<p>From the Set-up menu, use  and  buttons to select the Pulse width option.</p>
	<p>Press  to enter the selection routine. The current setting will flash.</p>
<p>Use  and  buttons to choose pulse width. On Completion of the entry procedure, press  to confirm the setting and press  to return to the main set up menu.</p>	

**4.7 Communication**

There is a RS485 port can be used for communication using Modbus RTU protocol. For Modbus

RTU, parameters are selected from Front panel.

#### 4.7.1 RS485 Address










(The range is from 001 to 247)









	<p>From the Set-up menu, use  and  buttons to select the Address ID</p>
	<p>Press  button to enter the selection routine. The current setting will be flashing.</p>
	<p>Use  and  buttons to choose Modbus Address(001 to 247)</p>
<p>On completion of the entry procedure, press  button to confirm the setting and press  button to return the main set-up menu.</p>	



#### 4.7.2 Baud Rate

	<p>From the Set-up menu, use  and  buttons to select the Baud Rate option.</p>
--	--











	<p>Press  to enter the selection routine. The current setting will flash.</p>
	<p>Use  and  buttons to choose Baud rate 2.4k, 4.8k, 9.6k, 19.2k, 38.4k</p>
<p>On Completion of the entry procedure, press  to confirm the setting and press  to return to the main set up menu.</p>	

#### 4.7.3 Parity

	<p>From the Set-up menu, use  and  buttons to select the Parity option.</p>
	<p>Press  to enter the selection routine. The current setting will flash.</p>
	<p>Use  and  buttons to choose Parity (EVEN / ODD / NONE)</p>




On completion of the entry procedure, press  to confirm the setting and press  to return to the main set up menu.

#### 4.7.4 Stop bits


	<p>From the Set-up menu, use  and  buttons to select the Stop Bit option.</p>
	<p>Press  to enter the selection routine. The current setting will flash.</p>
	<p>Use  and  buttons to choose Stop Bit (2 or 1)</p>
<p>On completion of the entry procedure, press  to confirm the setting and press  to return to the main set up menu.</p>	

#### 4.8 CLR

The power sensor provides a function to reset the maximum demand value of current and power.

	<p>From the Set-up menu, use  and  buttons to select the reset option.</p>
---	--





## 5 Specifications

### 5.1 Measured Parameters

The unit can monitor and display the following parameters of four phase four wire(3p4w) supply.

#### 5.1.1 Voltage and Current

Phase to neutral voltages 100 to 289V a.c.

Voltages between phases 173 to 500V a.c.

Percentage total voltage harmonic distortion (THD%) for each phase to N

Percentage voltage THD% between phases

Current THD% for each phase

#### 5.1.2 Power factor and Frequency and Max. Demand

Frequency in Hz

Instantaneous power:

- Power 0 to 3600 MW
- Reactive Power 0 to 3600 MVAr
- Volt-amps 0 to 3600 MVA

Maximum demanded power since last Demand reset Power factor

Maximum neutral demand current, since the last Demand reset (for three phase supplies only)

#### 5.1.3 Energy Measurements

- Imported active energy 0 to 9999999.9 kWh
- Exported active energy 0 to 9999999.9 kWh
- Imported reactive energy 0 to 9999999.9 kVArh
- Exported reactive energy 0 to 9999999.9 kVArh
- Total active energy 0 to 9999999.9 kWh
- Total reactive energy 0 to 9999999.9 kVArh

### 5.2 Measured Inputs

Voltage inputs through 4-way fixed connector with 2.5mm<sup>2</sup> stranded wire capacity. four phase four wire(3p4w) unbalanced. Line frequency measured from L1 voltage or L3 voltage.

Three current inputs (six physical terminals) with 2.5mm<sup>2</sup> stranded wire capacity for connection of external CTs. Nominal rated input current 5A or 1A a.c. Rms.

### 5.3 Accuracy

- Voltage 0.5% of range maximum
- Current 0.5% of nominal
- Frequency 0.2% of mid-frequency
- Power factor 1% of unity (0.01)
- Active power (W)  $\pm 1\%$  of range maximum
- Reactive power (VAr)  $\pm 2\%$  of range maximum
- Apparent power (VA)  $\pm 1\%$  of range maximum
- Active energy (Wh) Class 1 IEC 62053-21
- Reactive energy (VARh)  $\pm 2\%$  of range maximum
- Total harmonic distortion 1% up to 31st harmonic

### 5.4 Auxiliary Supply

Two-way fixed connector with 2.5mm<sup>2</sup> stranded wire capacity.

85 to 275V a.c. 50/60Hz  $\pm 10\%$  or 120V to 380V d.c.  $\pm 20\%$ . Consumption < 10W.

### 5.5 Interfaces for External Monitoring

Three interfaces are provided:

- an RS485 communication channel that can be programmed for Modbus RTU protocol
- an relay output indicating real-time measured energy.(configurable)
- an pulse output 3200imp/kWh (not configurable)

The Modbus configuration (Baud rate etc.) and the pulse relay output assignments (kW/kVArh, import/export etc.) are configured through the Set-up screens.

#### 5.5.1 Pulse Output

The pulse output can be set to generate pulses to represent kWh or kVArh.

**Rate** can be set to generate 1 pulse per:

0.01 = 10 Wh/VArh

0.1 = 100 Wh/VArh

1 = 1 kWh/kVArh

10 = 10 kWh/kVArh

100 = 100 kWh/kVArh

**Pulse width** 200/100/60 ms.

**Relay Rating** 240V ac 50mA

#### 5.5.2 RS485 Output for Modbus RTU

For Modbus RTU, the following RS485 communication parameters can be configured from the Set-up menu:

**Baud rate** 2400, 4800, 9600, 19200, 38400

**Parity** none(default)/odd/even

**Stop bits** 1 or 2

**RS485 network address** *nnn* – 3-digit number, 1 to 247

**Modbus™ Word order** Hi/Lo byte order is set automatically to normal or reverse. It cannot be configured from the set-up menu.

### 5.6 Reference Conditions of Influence Quantities

Influence Quantities are variables that affect measurement errors to a minor degree. Accuracy is verified under nominal value (within the specified tolerance) of these conditions.

- Ambient temperature 23°C ±1°C
- Input waveform 50 or 60Hz ±2%
- Input waveform Sinusoidal (distortion factor < 0.005)
- Auxiliary supply voltage Nominal ±1%
- Auxiliary supply frequency Nominal ±1%
- Auxiliary supply waveform (if AC) Sinusoidal (distortion factor < 0.05)
- Magnetic field of external origin Terrestrial flux

### 5.7 Environment


- Operating temperature -25°C to +55°C\*
- Storage temperature -40°C to +70°C\*
- Relative humidity 0 to 90%, non-condensing
- Altitude Up to 2000m
- Warm up time 1 minute
- Vibration 10Hz to 50Hz, IEC 60068-2-6, 2g
- Shock 30g in 3 planes

\*Maximum operating and storage temperatures are in the context of typical daily and seasonal variation.

### 5.8 Mechanics


- DIN rail dimensions 72 x 94.5 mm (WxH) per DIN 43880
- Mounting DIN rail (DIN 43880)
- Sealing IP20 (minimum)
- Material Self-extinguishing UL94 V\_0

## 6 Dimensions




## 7 Installation

Three phase three wires



Three phase four wires



Single phase two wires

