Push buttons

1 way		Polar white	**SM11PW**
		Soft black	**SM11SB**
		Elox silver	**SM11ES**
		Ivory	**SM11IW**
1 way with indicator		Polar white	**SM11PWIN**
		Soft black	**SM11SBIN**
		Elox silver	**SM11ESIN**
		Ivory	**SM11IWIN**
up / down		Polar white	**SM11PWNT10**
		Soft black	**SM11SBNT10**
		Elox silver	**SM11ESNT10**
		Ivory	**SM11IWNT10**

From:
https://wiki.hiq-home.com/ -

Permanent link:
https://wiki.hiq-home.com/doku.php?id=en:hiq_hw:tem-buttons&rev=1563950353

Last update: **2019/07/24 06:39**