

Commissioning

Strictly follow [Safety instructions](#)!

Mounting

Mount Robotina charger (EVSE), PM1-E-D & PM3-E-D power sensors as well as wireless modbus WM-1 & relay WR-1 to a suitable place. For more details, please read here [Hardware](#).

Wiring

Connect EVSE to the home LAN. Wire WM-1 module with power sensor and WR-1 relay with device (e.g. heat pump, el. radiator).

Configuration

Install and run [Robotina Charger](#) on your PC. With the “**autodetect**” button, the application will locate EVSE in the local network. Enter **names**, select **icons** for all sources and consumers.

From:
<http://wiki.hiq-home.com/> -

Permanent link:
http://wiki.hiq-home.com/doku.php?id=en:robotina_charger:commissioning&rev=1670577054

Last update: **2022/12/09 09:10**

