

# Commissioning

Strictly follow [Safety instructions](#)!

## Mounting

Mount Robotina charger (EVSE), [PM1-E-D](#) & [PM3-E-D](#) power sensor as well as [WM-1](#) & [WR-1](#) to a suitable place. For more details, please read [Hardware](#).

## Wiring

Connect EVSE to the home LAN. Wire WM-1 module with power sensor and WR-1 relay with device (e.g. heat pump, el. radiator). For more details, please read [Wiring](#).

## Configuration

Install and run [Robotina Charger](#) on your PC. Use **autodetect** button to discover EVSE in local network. Enter **names**, choose **icons** for all sources and consumers. Add WM-1 and WR-1 module by running **WM / WR binding** and scan for power sensors and wireless relay.

From:  
<http://wiki.hiq-home.com/> -

Permanent link:  
[http://wiki.hiq-home.com/doku.php?id=en:robotina\\_charger:commissioning&rev=1671027133](http://wiki.hiq-home.com/doku.php?id=en:robotina_charger:commissioning&rev=1671027133)

Last update: **2022/12/14 14:12**

