

HEMS HW Selection table

HEMS sets

| Name | Code | Description | Contains |
|-------------|---------------------|--|--|
| HEMS 1P set | HEMS-1P-D-02 | HEMS, single phase power sensor and current transformer included | MC-230 PM1-E-D-CT CT1-E-50 |
| HEMS 3P set | HEMS-3P-D-02 | HEMS, three phase power sensor included | MC-230 PM3-I-D |

HEMS devices

| Name | Code | Description | Mounting |
|---------------------------|----------------------------|---|--------------|
| Home Linker | HL | Home linker, connecting Home to HIQ Universe | DIN rail, 6M |
| HEMS G2 controller | MC-230 | HEMS controller, up to 6 energy sources and 4 managed consumers | DIN rail, 6M |
| Three-phase power-sensor | PM3-I-D | 3-phase power sensor, direct connection | DIN rail, 3M |
| Single-phase power-sensor | PM1-E-D | 1-phase power sensor, direct connection | DIN rail, 1M |
| Single-phase power-sensor | PM1-E-D-CT | 1-phase power sensor, current transformer | DIN rail, 1M |
| Current transformer | CT1-E-50 | Split core current transformer 50A | |
| Temperature sensor | ES | Digital temperature sensor | |

From:
<http://wiki.hiq-home.com/> -

Permanent link:
<http://wiki.hiq-home.com/doku.php?id=en:hems:hardware&rev=1562827512>

Last update: **2019/07/11 06:45**

