


HEMS v1.2.0 wiring

MC-230


Wiring of default configuration.

NOTE: several different configurations can be configured with [HEMS Configurator](#).




Network → MC-230, IOT-L2-2 and optionally 4G modem

Default connection to the LAN:





Default connection via 4G modem:




Optional connection to the LAN:


NOTE: optional connection has to be configured on the cloud service. Please contact support. The same applies to specific network requirements, i.e. static IP address.




PM3-I-D


PM1-E-D



PM1-E-D-CT

PM3-E-D-CT



Power-sensors orientation

From:

<http://wiki.hiq-home.com/> -

Permanent link:

http://wiki.hiq-home.com/doku.php?id=en:hems_v1_2_0:methods_resources:wiring&rev=1632150594

Last update: 2021/09/20 15:09

