HIQ UNIVERSE

HIQ Universe is a cloud service that enables:

- An overview of current power consumption
- An overview of the history of electrical power and energy consumption and production
- An overview and control of connected devices

Access point: https://my.hiq-universe.com

HIQ Universe Log-in

HIQ Universe Smart spaces	× +		- 🗆 X
← → C' ŵ	0 Attps://my.hiq-universe.com/rs/sa/login/index	⊌ ☆	⊻ II\ 🖸 📽 😇 🗏
	•		
	<u>ā</u> r		
	Smart spaces		
	Username or email		
	Password		
	Stay signed in		
	Sign in		
	Forgot your password? Create new account		
	Terms, Privacy		

Log in with your username or email and password to see your HIQ Universe subscription dashboard.

To reset forgotten password click on "Forgot your password?"

To create new account click on "Create new account".

Create HIQ Universe account

HIQ Universe Create new account X	+		-		×
$\leftarrow \rightarrow$ C $\textcircled{0}$	https://my.hiq-universe.com/rs/sa/register/index	⊠ ☆	\ □	3 🔋	≡
	C reate new account				^
	Choose your username				
	Your first name and last name				
	Email address				
	UTC+2:00 Africa/Blantyre				
	Create a password				
	Confirm your password				
	I'm not a robot				
	Accept Terms and Conditions				
					Ŷ

In the appropriate fields, enter:

- Username
- First and Last name
- E-mail address
- Timezone
- Password

Click on "I'm not a robot"


Accept Terms and Conditions.

Click on Create account.

A confirmation link will be sent to your email address.

Proceed to "HIQ Universe Log-in" screen.

Reset forgotten password



In the appropriate field, enter email address.

Click on "I'm not a robot"

Click on "Reset password".


You will receive email with password reset link.

Last update: 2021/11/: 15:06	en:hems_v1_2_0:universe http://wiki.hiq-home.com	/doku.php?id=en:hems_v1_2	2_0:universe&rev=163672959
HIQ Universe Reset password	× +	⊌ ☆	⊻ II\ © ®° 0 ≡
	Ð		
	Reset password		
	New password		
	Repeat password Save new password		
	Save new passivoju		
	Terms, Privacy		

Enter new password and click on "Save new password".

Proceed to "HIQ Universe Log-in" screen.

Add HEMS controller




Enter HEMS activation code from "HEMS Quick Set-Up Guide" found in HEMS box.

userr	ame
email	
passv	sord
	ACTIVATION CODE SN-0012345A-85212FC25-685D-BEBE

HIQ Universe subscription dashboard

Last update: 2021/11/12 15:06




You will see tiles for all your subscribed HIQ Universe devices and services.

Go to Main HEMS view by clicking on HEMS tile or

add new HEMS device by clicking on blank tile with + sign.

"User profile set-up" is invoked by clicking on user name on top right.

Main HEMS view



Main HEMS page consists of 3 sections:

- "Title and view selection row" at the top
- "Power flow chart" on left side
- "Power and energy time-plot" on right

Title and view selection row


Hems 1.2.0 <u>4</u> Daily Monthly Yearly () () 2021/03/30 ~ ()	09:18
--	-------

From the left:

- Application name → HEMS name
- Lighting icon → time-plot displays energy or power
- Currency icon → time-plot overlays currency graph
- Daily → time-plot displays power
- **Monthly** → time-plot displays energy per day
- Yearly → time-plot displays energy par month
- Target icon → time-plot go to now
- < → time-plot goes to previous term
- > \rightarrow time-plot goes to next term
- Date → Select term for time-plot

- **Download icon** → Download "csv" data for displayed time-plot period
- Location of HEMS installation
- Time at HEMS installation site.

Power flow chart



Displays actual power flow with:


- Power sources (Local PV, wind, co-generation plants) at top
- Grid (divided by tariffs) on left side
- Storage (battery) systems on right side and
- Consumers on bottom.

Unused items are soft greyed out with X. Items without actual power are displayed as dots. Clicking on a devices displays current power flow for selected device.



On bottom is time-plot for selected time period (in title row). By clicking on time plot a term for legend display is selected. Above there is power/energy legend.

Side menu



Side menu is activated by clicking menu icon (three horizontal lines at top-left). Menu items are dynamically created so they can be different for each user. Typical menu items from top:

- Home page → section with all your subscribed HIQ Universe devices and services
 - Hems 1.2.0 → "Main HEMS view"
 - Settings page → "HEMS settings"
 - My Things → "My Things"
- **TOOLS** → section with general site tools
 - Profile \rightarrow "User profile set-up"
 - Reports→ "System reports"
 - \circ Sign out → Log off from HIQ Universe

HEMS settings

← → C	HIQ Universe Sett	tings page × +		_		×
Settings page Device HEMS-SN-0042FE-c30567- Dorniz-Wiki MC serial number ? Device name Hems 1.2.0 Location Location name Location latitude Location latitude Location latitude Time Zone UTC+2:00 Europe/Ljubljana v Energy price Currency Euro v Low tariff price (€/kWh) 0.122 High tariff price (€/kWh) 0.122	← → ♂ ଢ [🖲 🔒 https://my.hiq-univers 🗏 🛛 70% 🚥	$\mathbf{\overline{v}}$	III\ 🗉) »	≡
Device HEMS-SN-0042FE-c30567- Dorniz-Wiki MC serial number ? Device name Hems 1.2.0 Location Location Location name Location latitude Time Zone UTC+2:00 Europe/Ljubljana V Energy price Currency Euro Low tariff price (€/kWh) 0.122 High tariff price (€/kWh) 0.122	\equiv	Γ.				^
HEMS-SN-0042FE-c30567- Dorniz-Wiki MC serial number ? Device name Hems 1.2.0 Location Location name Location name Location latitude Location longitude Time Zone UTC+2:00 Europe/Ljubljana ♥ Energy price Currency Euro ♥ Low tariff price (€/kWh) 0.122 High tariff price (€/kWh) 0.122	Settings page					
Dorniz-Wiki MC serial number Pevice name Hems 1.2.0 Location Location name Location latitude Location longitude Time Zone UTC+2:00 Europe/Ljubljana Energy price Currency Euro Low tariff price (€/kWh) 0.122	Device					
Device name Hems 1.2.0 Location Location name Location latitude Location longitude Time Zone UTC+2:00 Europe/Ljubljana Currency Euro Low tariff price (€/kWh) 0.122						
Location Location name Location latitude Location longitude Time Zone UTC+2:00 Europe/Ljubljana ✓ Energy price Currency Euro ✓ Low tariff price (€/kWh) 0.122	MC serial number	?				
Location name Location latitude Location longitude Time Zone UTC+2:00 Europe/Ljubljana ✓ Energy price Currency Euro ✓ Low tariff price (€/kWh) 0.122 High tariff price (€/kWh) 0.122	Device name	Hems 1.2.0				
Location latitude Location longitude Time Zone UTC+2:00 Europe/Ljubljana ✓ Energy price Currency Euro ✓ Low tariff price (€/kWh) 0.122 High tariff price (€/kWh) 0.122	Location					
Location longitude Time Zone UTC+2:00 Europe/Ljubljana V Energy price Currency Euro V Low tariff price (€/kWh) 0.122 High tariff price (€/kWh) 0.122	Location name					
Time Zone UTC+2:00 Europe/Ljubljana ✓ Energy price Currency Euro ✓ Low tariff price (€/kWh) 0.122 High tariff price (€/kWh) 0.122	Location latitude					
Energy price Currency Low tariff price (€/kWh) High tariff price (€/kWh)	Location longitude					
Currency Euro Low tariff price (€/kWh) 0.122 High tariff price (€/kWh) 0.122	Time Zone	UTC+2:00 Europe/Ljubljana 🗸				
Currency Euro Low tariff price (€/kWh) 0.122 High tariff price (€/kWh) 0.122						
Low tariff price (€/kWh) 0.122 High tariff price (€/kWh) 0.122	Energy price					
Low tariff price (€/kWh) 0.122 High tariff price (€/kWh) 0.122						
High tariff price (€/kWh) 0.122	-	Euro				
		0.122				
Feed-in tariff price (€/kWh) 0.122						
	Feed-in tariff price (€/kWh)	0.122				

Basic settings and info about HEMS.

Sections:

- Settings:
 - Device serial number
 - Device name
 - Location name and coordinates, timezone
- Energy price: per tariff energy price
- Timeplots range: ranges for various timeplots
- Share your device: manage device sharing guest accounts

My Things

HIQ Universe My Things	× +	683/iot_hems2 (60%) 🤝	- □ ×
	https://my. hiq-universe.com /rs/pp/1	605/10t_nems2_ 60% ···· •	^
≡			∧
My things -			
Consumers			^
Poraba pritličje >	1. nadstropje	Mansarda >	TČ ogrevanje >
	Power: 27 W	Power. 325 W	Dower: OW
Settings 🗸 🗸	Settings 🗸 🗸	Settings V	Settings 🗸
History ~	History ~	History ~	History
TČ sanitarna >	Kuhinja >	Pečica >	Polnilnica A >
Power: I35 W	O W	Power: OW	State: Available Phases: 3 phases power: 0 W EVSE max 20 A Max current: 20 Last session: 0 h 0 min Energy: 0 Wh
Settings 🗸 🗸	Settings 🗸 🗸	Settings V	Settings ~
History ~	History ~	History ~	History ~
Production and grid	^	·	·
PV >	Grid		
Power: 7728 W	Voitage L1: 225 V Voitage L2: 226 V Voitage L3: 226 V Voitage L3: 230 V Frequency: 50.02 Hz Tariff: L0 Current L1: -11.8 A Current L2: -18.8 A Current L3: -11.3 A		
	Settings ~		
History ~	History ~		
Storage			~
Sensors			
JensUIS			^

My Things GUI could be accessed within the HiQ Universe platform by clicking the My Things item within the main menu. Individual devices are presented as a group of cards, divided on four groups:

• Consumers

- Up to 8 consumers
- On/Off control
- Overview of energy and status
 - Settings:
 - Manual override (Minute countdown of manual control until cloud can perform optimizations again)
 - Cloud optimizations with timetable
 - Current limiter with priorities
 - History:

- Power overview
- Production and grid
 - Overview of grid and up to 3 other energy sources
- Storage
 - Overview of up to 2 battery sources
- Sensors
 - Supported for temperature and humidity sensor

Consumers

▲ >

Polnilnica

	State:	Available
	Phases:	3 phases
()	Power:	o w
	EVSE max:	20 A
	Max current:	20 🖨 🗚
	Last session:	0 h 0 min
	Energy:	0 Wh

Settings		^
Manual override:		0
Smart g	grid	
Cloud optimization:		\checkmark
Smart grid status:		Idle
Enabled:	from:	0 ~: 0 ~
	to:	0 ~: 0 ~
Max duration:		
		15 🗡 min
Max request:		1 🗸
Suspend time:		15 🗠 min
Current li	miter	
Limiter priority:		limit first 🗠 min
History		^
Span Date		^
-		^
Span Date		
Span Date Day 2021/03/31		Phase L1: 0 W A Phase L2: 0 W
Span Date Day 2021/03/31		Phase L1: 0 W 🔺
Span Date Day 2021/03/31 L0		Phase LI: 0 W A Phase L2: 0 W Phase L3: 0 W
Span Date Day 2021/03/31 L0		Phase LI: 0 W A Phase L2: 0 W Phase L3: 0 W
Span Date Day V 2021/03/31 10 0.5		Phase LI: 0 W A Phase L2: 0 W Phase L3: 0 W
Span Date Day V 2021/03/31 10 0.5		Phase LI: 0 W A Phase L2: 0 W Phase L3: 0 W
Span Date Day ♥ 2021/03/31 1.0 0.5 0.0		Phase LI: 0 W A Phase L2: 0 W Phase L3: 0 W
Span Date Day V 2021/03/31 10 0.5 0.0 -0.5 -1.0		Phase LI: 0 W A Phase L2: 0 W Phase L3: 0 W

Consumers present devices, that consume electric energy. Within the group of Consumers, the first card present a general consumption of the object - a background consumption. The following

items present real controllable devices, such as EV charger, Heat pump, wireless socket, etc. An example of a device is shown in the following image.

The form of a card of each consumer is composed of the general part, history and settings part.

General part contains:

- Name of a device, which can be changed by user.
- Icon (button) enables toggling the device operation state (Switch on / Switch off).
- **State** label contain the information of device operation state.
- **Phases** label contain the information of EV utilized phases.
- **Power** label contain the information of device consumption power in watts.
- EVSE max label contains EVSE max charging current,
- Max current label is user desired max charging current, which can be changed by user.
- Last session label contains the information of charging duration and energy.


Settings:

- **Manual override** are minutes after switch on/off button is pressed that the smart-grid service is not allowed to switch on/off the device.
- Cloud optimization enables or disables smart grid service.
- Smart grid status label shows smart grid operation state with the following states:
- **Enabled** section specify the temporal range between **from** and **to** in the form of *hh:mm*, in which the device is allowed to be switched off from according to the smart-grid service. If **from** is larger than **to**, then temporal range is the opposite. If **from** and **to** are equal, then the smart-grid service is enabled 24 hours a day.
- **Max duration** setting limits the duration of time, the smart-grid service switches off (activates) the device. After smart-grid service activates the device, the device will deactivate (switch back on) after max-duration minutes at the latest.
- **Max request** setting limits the maximum daily activations from the smart-grid service.
- **Suspend time** presents the time in minutes, which has to pass between two activations (between the stop of one activation and start of another).
- Limiter priority setting can be no limiter, limit last, limit second and limit first. If DCL is enabled and inactive a green warning icon is displayed on the card. If DCL is active the icon turns yellow and if DCL is disabled there is no icon on the card. Limit first is a group of devices that are dynamically regulated first if the main grid current is over the preset threshold. If main grid current is still over the preset threshold, regulating other groups will follow with limit second and after that with limit last.

History:

• **History** part shows historical consumption of a device. The temporal range can be selected as daily, weekly, monthly or yearly. Daily and weekly range shows power consumption in watts, while monthly and yearly range shows energy consumption in kilowatt-hours. The interface enables time-frame selection and time-frame alignment to current time.

Production and grid



Producers present devices or systems that produce electrical energy. Example of such devices are solar power plant, wind power plant, diesel generator and others. An example on the following figure shows solar power plant.

General part contains:

Last update: 2021/11/12

- Name of a plant, which can be changed by user.
- Icon represent the type of producer.
- Voltage represents voltage of the grid.
- Frequency represents frequency of the grid.
- Tariff represents active tariff of the grid.

- **Current** represents current of the grid.
- **Power** label contain the information of device production power in watts.

Settings:

• **Dynamic Current Limiter** represents grid current threshold. The DCL will manage devices to keep the current under this threshold. Settings are per phase.

History:

• **History** part shows historical production of a device. The temporal range can be selected as daily, weekly, monthly or yearly. Daily and weekly range shows power production in watts, while monthly and yearly range shows energy production in kilowatt-hours. The interface enables time-frame selection and time-frame alignment to current time. Grid has additional current history.

Storage

Battery	
	charging 164 W
History	^
Span Date Day 2020/09/25	
500	Discharging 0 W 🔺
400	Charging 0 W
300	
200	
100	
0 00:00 04:00 08:00 12:00	16:00 20:00

Storage present battery as shown in an example figure on the left.

General part contains:


- **Name** of a battery, given by the user.
- **Icon** representing the battery.
- **Power** label contain the information of charging or discharging power in watts.

History:

• **History** part shows historical charging or discharging power of a device. The temporal range can be selected as daily, weekly, monthly or yearly. Daily and weekly range shows

power charging or discharging in watts, while monthly and yearly range shows energy charged or discharged in kilowatt-hours. The interface enables time-frame selection and time-frame alignment to current time.

Sensors



Sensors present devices or systems that measure various quantities, such as temperature, humidity. The left figure represent a combined temperature and humidity sensor.

General part contains:

- Name of a sensor, which can be changed by user.
- **Icon** represent the type of sensor.
- Temperature label contain the information of temperature measurement in °C.
- Humidity label contain the information of relative humidity in %.

History:

• **History** part shows historical sensor measurements. The temporal range can be selected as daily, weekly, monthly or yearly. The interface enables time-frame selection and time-frame alignment to current time.

User profile set-up

HIQ Universe Profile	× +			- 🗆	×
$\epsilon \rightarrow$ C $rac{1}{2}$	https://my.hiq-universe.com/rs/s:	₽ 90% … 🛛	☆ ⊻ ≡/	1 2 0	≡
≡		ſ.			^
Basic information					
Username					
Created					
Previous login					
Last login Last password change					
Use language	English	~			
jj-					
Profile					
Main realm		~			
Full name					
Email address					
Timezone	UTC+0:00 WET	~			
Save changes Password					
Old password					
New password					
Repeat password					
Change password					
Persistent logins					
ID No persistent logins	Last login From IP Del	ete			
					~

Basic information section:

- Username
- Created date and IP
- Previous and last login date and IP
- Last password change date and IP
- User language

Profile section:

• Main realm display

• Full name, email address and timezone edit fields

Password:

• Fields for password changing

Persistent logins:

• Data of access from persistent logins

System Reports

HIQ Universe Reports	×	+								—		×
← → ♂ ଢ	🛛 🔒 https	://my.hiq-universe.co	m/rs/sa/user_r	eports/index	•••	• 🖾	☆	⊻	111	•	3 😳	≡
=					/,∖.							
Report configuration	IS											
Report						Proj	ect			Ser	nd email	
There are no active report	s for your devic	ces.										
Save configurations												
4	A robotina											
	OIC - Hrpelje 3 SI-6420 Kozina		+386(0)5 689 info@robotin			Com Supp	pany					
	Slovenia		www.robotin			Wiki						
			é se ca	1								

System generated reports can be found here.

Permanent link: http://wiki.hiq-home.com/doku.php?id=en:hems_v1_2_0:universe&rev=16 36729594



HIQ UNIVERSE

Last update: 2021/11/12 15:06