

Push buttons

1 way			Polar white	SM11PW
			Soft black	SM11SB
			Elox silver	SM11ES
			Ivory	SM11IW
1 way with indicator			Polar white	SM11PWIN
			Soft black	SM11SBIN
			Elox silver	SM11ESIN
			Ivory	SM11IWIN
up / down			Polar white	SM11PWNT10
			Soft black	SM11SBNT10
			Elox silver	SM11ESNT10
			Ivory	SM11IWNT10

From:
<https://wiki.hiq-home.com/> -

Permanent link:
https://wiki.hiq-home.com/doku.php?id=en:hiq_hw:tem-buttons&rev=1563950353

Last update: **2019/07/24 06:39**

