



Maintenance, Warranty and Disposal

HARDWARE MAINTENANCE

LCS controller MC-230

- 10 8A relay output module LC-10-IQ
- 8 10A relay output module LC-8-IQ
- Universal dimmable module LD-P4-IQ
- DALI module LD-D8-IQ
- DMX module LD-DMX-IQ
- Led stripe module LD-V\$-IQ

| | WIRED | | | | WIRELESS | | |
|-----------------------------|---|---|---|--|---|---|---|
| | INPUTS ON LC/LD- MODULES | FLUSH MOUNT MODULES | SCENE PANELS TOUCH BUTTONS | MOTION SENSORS | WALL BUTTONS | SOFT REMOTES | MOTION SENSORS |
| HIQ LCS INPUT DEVICES |  LC-8-IQ LC-10-IQ LD-P4-IQ LD-D8-IQ |  SW-W3-IQ O2-IQ |  Bx-HI SC-4T-IQ |  IR-C6-IQ IR-C6W-IQ IR-580-IQ |  EN-WS-WT-IQ |  EN-SR-xx-IQ |  EN-MS-WT-IQ |

- any push buttons on binary inputs of [LC-10-IQ](#) or [LC-8-IQ](#)
- [Scene panel](#)
- [Touch buttons](#)
- EnOcean wireless [Wall button](#) or [Soft remote](#)
- [On wall or on ceiling long range motion sensor](#)
- EnOcean wireless [false ceiling motion sensor](#)

From:
<http://wiki.hiq-home.com/> -

Permanent link:
http://wiki.hiq-home.com/doku.php?id=en:ms_main:maintenance_warranty_and_disposal&rev=1608980490

Last update: **2020/12/26 11:01**

