

## HIQ linkers

name	description	code	status	mounting
<a href="#">IOT Linker 2 Ethernet Port</a>	Central high function linker (HIQ Universe)	IOT-L2-2	available	DIN rail, wall
<a href="#">4G LTE USB modem for IOT linker</a>	USB wireless modem for IOT linker	IOT-L2-W	available	USB port on IOT-L2-2 linker

## Accessories

Nothing found

## Power sensors

name	description	code	status	mounting
<a href="#">Single phase power-sensor</a>	1-phase power sensor, DIN rail	PM1-E-D	available	Cabinet, DIN rail 1M
<a href="#">Single phase power-sensor, CT</a>	1-phase power sensor, DIN rail, CT	PM1-E-D-CT	available	Cabinet; DIN rail 1M
<a href="#">Three phase power-sensor</a>	3-phase power sensor, DIN rail	PM3-I-D	available	Cabinet; DIN rail 3M
<a href="#">Three phase power sensor</a>	3-phase power sensor, DIN rail	PM3-E-D	available	Cabinet, DIN rail 4M
<a href="#">Three phase power sensor, CT</a>	3-phase power sensor, DIN rail, CT	PM3-E-D-CT	available	Cabinet; DIN rail 4M
<a href="#">1-ph current transformer</a>	1-phase split core current transformer, 50A	CT-1-E-50	available	on wire
<a href="#">3-ph current transformer</a>	3-phase split core current transformer, 50-400A	CT-3-E-XX	available	on wire

From:  
<http://wiki.hiq-home.com/> -

Permanent link:  
[http://wiki.hiq-home.com/doku.php?id=en:robotina\\_charger:hardware&rev=1669801377](http://wiki.hiq-home.com/doku.php?id=en:robotina_charger:hardware&rev=1669801377)

Last update: **2022/11/30 09:42**

