

## HIQ-HC FW upgrade

Download and save CyPro IDE		CyPro
Run and install it		
Download and open project		hc-iq_v127.cyp
Find Home Controller NAD (sticker on top of HC)		<input type="checkbox"/>
Select Home Controller	Hardware Setup [F5]... → Autodetect	<input type="checkbox"/>
Send Program	Program → Send [F9]	<input type="checkbox"/>
Start PLC program	Program → Start PLC [F11]	<input type="checkbox"/>

## HIQ-DC FW upgrade

Download and unzip CybroIEXManager		CyBrolexManager
Download and unzip Device Controller FWs		firmware.zip
Start CybroIEXManager.exe		<input type="checkbox"/>
Scan for Home controller	[Scan]	<input type="checkbox"/>
Select Home Controller		<input type="checkbox"/>
Scan for connected IEX Device Controllers	[Scan IEX]	<input type="checkbox"/>
For each connected device type open HIQ-DC FW	[Open]	<input type="checkbox"/>
Send Firmware to HIQ-DC	[Send]	<input type="checkbox"/>

From:

<http://wiki.hiq-home.com/> -

Permanent link:

<http://wiki.hiq-home.com/doku.php?id=partners:firmware&rev=1487770764>

Last update: **2017/02/22 13:39**

