

## HIQ-DC FW upgrade

Download and unzip CybroIEXManager		<a href="#">CyBrolexManager</a>
Download and unzip Device Controller FWs		<a href="#">firmware.zip</a>
Start CybroIEXManager.exe		<input type="checkbox"/>
Scan for Home controller	[Scan]	<input type="checkbox"/>
Select Home Controller		<input type="checkbox"/>
Scan for connected IEX Device Controllers	[Scan IEX]	<input type="checkbox"/>
For each connected device type open HIQ-DC FW	[Open]	<input type="checkbox"/>
Send Firmware to HIQ-DC	[Send]	<input type="checkbox"/>

From:  
<http://wiki.hiq-home.com/> -

Permanent link:  
<http://wiki.hiq-home.com/doku.php?id=partners:firmware&rev=1487770771>

Last update: **2017/02/22 13:39**

