# **Alarms and notifications**

The following page provides the description of the alarms and reports that can be configured and used by end-users.

## Description

2025/09/03 22:22

GoFlex HEMS support the following alarms:

- FOA service is not available (for more than 1 hour)
- IoT linker is offline (for more than 1 hour)
- HEMS controller is offline (for more than 1 hour)

and notification:

• Cyclic device begin the operation cycle

## **Configure alarms and notifications**

From side menu select **Reports** as shown in the following figure.

HQ Universe   Reports	x		100		- 0	×
€ → C @	🛞 🚔 https://my.hiq-universe.com/m/us/user_m	🖂 🟠	Q, HB	IIV.	0 \$	≡
×		Ŵ	Dom	anZupancic		
HOME PAGE						
7-PRE035						
My Things					Send en	hail
	104004(CY-35)					
TOOLS						
Profile						
Reports						
Sign out						
	+366(0)5 609 2 info@robetina www.robetina	com	Company Support Wilki			
	1 7 0					
	M SMID v. 212/2, Cythrologitierver Che		ns, Fugue loons			

Apply the following steps (see figure below):

- 1. Check send email checkbox
- 2. Select language (optional, default is English)

Last update: 2019/09/06 en:goflex\_hems:universe:alarms\_notifications http://wiki.hiq-home.com/doku.php?id=en:goflex\_hems:universe:alarms\_notifications&rev=1567768350 11:12

### 3. Save changes

HIQ Universe   Reports	×			(0)0000
-)→ ୯ @	Inttps://my.hiq-universe	com/n/u/usec_= *** 🖾 👌	Q, Md	IN 10 🕸 🗉
	niverse 📅	Ţ	DomenZup	ancic
eport configuration	s			
Report     Events noti	fication - HEMS-SN-004004(CV-35	0	1. Check 'Send email' checkb	Send email
#7 Use language		-		
Hy language	<ul> <li>2. Select preferred language</li> </ul>			
Save configurations	* There are some unsaved char	opes 3. Save settings		
5	Probatina			
	OIC - Hrpelje 38	+386(0)5 689 2020	Company	
	SI-6420 Kozina Slovenia	info@robotina.com www.robotina.com	Support Wiki	
	and the second s	HH HUSDOW BLOOM	1100	
		f ¥ 🖬 🕫		
	Powered by SMID x 2.12./2	CyBrologilierver Credits: Famfamfam Silk I	cans, Fugue loons	

### Note for site-managers

Site manager is able to do similar procedure, as described in previous section for end-user. In addition to end-users, he can select multiple HEMS instances from his area and check **send-email** per instance, he would like to monitor and recieve email notifications.

