


HEMS v1.2.0 wiring


MC-230

Wiring of default configuration.

NOTE: several different configurations can be configured with [HEMS Configurator](#).




IOT-L2-2




Network → MC-230, IOT-L2-2 and optionally 4G LTE modem

Default connection to the LAN:





Default connection via 4G LTE modem:




Optional connection to the LAN:


NOTE: optional connection has to be configured on the cloud service. Please contact support.
The same applies to specific network requirements, i.e. static IP address.




PM3-I-D


PM1-E-D




PM1-E-D-CT

PM3-E-D-CT



WM-1

Power-sensors orientation



Control consumer by external signal

Connect external source to control device, e.g. thermostat signal on IX0 to control temperature by enabling/disabling connected device on QX0.


HEMS configurator

Using HEMS configurator settings page, set Digital 1 for consumer in this case water heater.

CONSUMERS	icon	output	man.time	P nominal
Water heater	Water heater	Digital-1	0 min	2500 W

Using HEMS configurator IO mux page, set QX0 to Digital 1 and IX0 to Enable consumer 1:

Select input/output type	out mode
QX0	Digital-1
QX1	/
QX2	/
QX3	/
IO12	/
IO13	/
IO14	/
IO15	/
IX0	Enable consumer-1
IX1	/
IX2	/



From:

<https://wiki.hiq-home.com/> -

Permanent link:

https://wiki.hiq-home.com/doku.php?id=en:hems_v1_2_0:methods_resources:wiring&rev=1635940881

Last update: 2021/11/03 12:01

