


# HEMS v1.2.x wiring


## MC-230

Wiring of default configuration.

NOTE: several different configurations can be configured with [HEMS Configurator](#).




## IOT-L2-2





## Network → MC-230, IOT-L2-2 and optionally LTE 4G modem

Default connection to the LAN:




Optional LAN connections:






Default connection via LTE 4G modem:

**NOTE:** All devices will have internet access via LTE modem which can result in high costs on your LTE account.





Optional LTE 4G modem connection:




**NOTE:** Specific network requirements, i.e. static IP address can be configured on the cloud service. Please contact [support](#).


## PM3-I-D




**PM1-E-D**


## PM1-E-D-CT



**PM3-E-D-CT**

## WM-1



**Power-sensors orientation**

## Control consumer by external signal

Connect external source to control device, e.g. thermostat signal on IX0 to control temperature by enabling/disabling connected device on QX0.


### HEMS configurator

Using HEMS configurator settings page, set Digital 1 for consumer in this case water heater.

CONSUMERS	icon	output	man.time	P nominal
Water heater	Water heater	Digital-1	0 min	2500 W

Using HEMS configurator IO mux page, set QX0 to Digital 1 and IX0 to Enable consumer 1:

Select input/output type	out mode
QX0 Digital-1	normal
QX1 /	normal
QX2 /	normal
QX3 /	normal
IO12 /	normal
IO13 /	normal
IO14 /	normal
IO15 /	normal
IX0 Enable consumer-1	normal
IX1 /	normal
IX2 /	normal



From:  
<http://wiki.hiq-home.com/> -

Permanent link:  
[http://wiki.hiq-home.com/doku.php?id=en:hems\\_v1\\_2\\_0:methods\\_resources:wiring&rev=1636125079](http://wiki.hiq-home.com/doku.php?id=en:hems_v1_2_0:methods_resources:wiring&rev=1636125079)

Last update: **2021/11/05 15:11**

