

# HEMS HW Selection table

## HEMS sets

| Name        | Code                | Description  | Contains   |
|-------------|---------------------|--|--|
| HEMS 1P set | <b>HEMS-1P-D-02</b> | HEMS, single phase power sensor and current transformer included | <a href="#">MC-230</a><br><a href="#">PM1-E-D-CT</a><br><a href="#">CT1-E-50</a> |
| HEMS 3P set | <b>HEMS-3P-D-02</b> | HEMS, three phase power sensor included                          | <a href="#">MC-230</a><br><a href="#">PM3-I-D</a>                                |

## HEMS devices

| Name                      | Code                       | Description   | Mounting     |
|---------------------------|----------------------------|---|--------------|
| HEMS G2 controller        | <a href="#">MC-230</a>     | HEMS controller, up to 6 energy sources and 4 managed consumers | DIN rail, 6M |
| Three-phase power-sensor  | <a href="#">PM3-I-D</a>    | 3-phase power sensor, direct connection                         | DIN rail, 4M |
| Single-phase power-sensor | <a href="#">PM1-E-D</a>    | 1-phase power sensor, direct connection                         | DIN rail, 1M |
| Single-phase power-sensor | <a href="#">PM1-E-D-CT</a> | 1-phase power sensor, current transformer                       | DIN rail, 1M |
| Current transformer       | <a href="#">CT1-E-50</a>   | Split core current transformer 50A                              |              |
| Temperature sensor        | <a href="#">ES</a>         | Digital temperature sensor                                      |              |

From:

<http://wiki.hiq-home.com/> -

Permanent link:

<http://wiki.hiq-home.com/doku.php?id=en:hems:hardware&rev=1538984128>

Last update: **2018/10/08 07:35**

